

ESCAPE RESPIRATORS Model: H 900 ABEK CO P P/N 117100000

Escape hood for self-rescue very easy to use that allows escaping from the polluted area in case of fire. The device is provided with filter for acrolein, Hydrogen chloride, Hydrogen cyanide, Carbon monoxide and dusts, fumes and mists and offers additional protection for ABEK type gases.

The respirator is contained in a practical bag with belt loops, ring for wall application and side rings for shoulder use and thanks to its reduced weight and size it can be carried for a complete shift so that it can be rapidly worn in case of accident.

All components of H 900 (hood, filter and bag) are made up of antistatic materials that make it suitable for use in potentially explosive atmospheres, since they do not generate electrostatic charges when rubbed. The device is therefore ATEX certified.



TECHNICAL DATA

Breathing resistance

Test flow (l/min)	Inhalatio	n (mbar)	Exhalation (mbar)		
	Max. standard	Measured	Max. standard	Measured	
95	8	5.4	5	2.5	

Gas Performance

Gas test	Test conc. (ppm)	Test flow rate (I/ min)	Test H.R. (ml/m³)	Breakthrough conc. (ppm)	Duration (min)		
Gastest					Requested	Measured	
Acrolein	100	30	70	10	> 15	> 90	
HCL	1000	30	70	0.5	> 15	115	
HCN	2500*	30	70	10	> 15	56	
	2500		20.7 g/m³ at 23-25℃	20	> 15	> 15	
	5000	20 cycles/min and		10	> 15	> 15	
CO	7500	1,5 l/stroke:			5	> 15	> 15
	10000			25	> 15	> 15	



ESCAPE RESPIRATORS Model: H 900 ABEK CO P P/N 117100000



Particle filtration performance

		Testeereel	Penetration (%)		
Filter type	Test flow (l/min)	Test aerosol	Max standard	Measured	
Р	95	NaCl	6	0.85	

ABEK gases performance

Additional protection tested according to the requirements of the DIN 58647-7 standard in terms of concentrations and flows. The ABEK protection is not subject to EC certification and has been tested only to give information about the use in environments with the presence of ABEK type gases.

Gas test		Test conc. (ppm)	Test flow rate (l/min)	Test H.R. (%)	Bre- akthrough conc. (ppm)	Duration (min)
A	$C_{6}H_{12}$	2500	30	70	10	8
В	Cl ₂	2500	30	70	0.5	6
	H₂S	2500	30	70	10	17
	H ₂ S	10000	30	70	20	5
	HCN	2500	30	70	10	> 15
E	SO ₂	2500	30	70	5	16
К	NH_{3}	2500	30	70	25	17

Inward Leakage (IL)

The Inward Leakage with SF6 gas shall be not greater than 2%. Medium IL value for H 900 is 0.34%.

LIMITATION FOR USE

Do not use in areas where the oxygen concentration is lower than 17 % in volume nor in presence of gases different from those clearly indicated. The filter isn't suitable for the protection against organic vapours whose boiling point is lower than 65 °C and Nitrogen Oxides.

The respirator, for standard definition, is designed for single use only.



ESCAPE RESPIRATORS Model: H 900 ABEK CO P P/N 117100000

CLASSIFICATION

Respirator complying with the provisions of Regulation PPE 2016/425/EU.

Filtering smoke hood CO P type, class 15 minutes, M type (to be carried on the person) according to EN 403:2004 standard. Additional ABEK protection tested according to DIN 58647-7:1997.

Non-electrical equipment as defined in Atex Directive 2014/34/EU. Below the details of ATEX marking:

II 1G Ex h IIC T6 Ga -> non-electrical appliances intended for use in the surface industry, where there is the possibility of explosive atmospheres due to the presence of gas - Zone 0

II 1D Ex h IIIC T85 ° C -> non-electrical appliances intended for use in the surface industry, where there is the possibility of explosive atmospheres due to the presence of dust - Zone 20.

MARKING

MATERIALS

Bag:Antistatic PVCHood:PVC coated cotton with PU collar and anti-fog treated PC visorHalf-mask:SiliconeFilter housing:PolypropyleneFilter media:Activated carbon, catalyst and filter paper

STORAGE

Store at temperatures between -20 and +50 ℃ and RH <80%.

WEIGHT

Respirator: 550 g approximately – Respirator and container: 750 g approximately.

DIMENSIONS / PACKING

The respirator, in its container, is sold singularly in a plastic bag which also includes the information notice. Dimensions of the respirator in its container: 130 x 120 x 300 mm.

SHELF LIFE

Respirators duly stored and in their original packaging will last five years from production. The expiry date is stamped onto the filter label and on the respirator container.

Upon expiration it is possible to extend the shelf life of the product for another 5 years, upon check by SPASCIANI or authorised dealer.

For more information please check the notes along with the products or the ones published on the website: www.spasciani.com

NOTE: SPASCIANI SpA does not take any responsibility for any possible and unintentional mistake and reserve the faculty of modify materials and technical characteristics of its products at any time and without any notice.

www.spasciani.com